




E-SWITCH®

# Beyond the Board



Termination Options for  
Panel Mount Switches



**E-SWITCH®**













Beyond the  
**Board**

| <b>ANTI-VANDAL (PV LINE)</b>  | <b>Wire Leads</b> | <b>Solder</b> | <b>Screw</b> | <b>Quick Connect</b> |
|---|-------------------|---------------|--------------|----------------------|
|  <b>PV0</b> Series Anti-vandal Switch            | ✓                 | ✓             |              |                      |
|  <b>PV1</b> Series Anti-vandal Switch            | ✓                 | ✓             | ✓            |                      |
|  <b>PV10</b> Series Anti-vandal Switch           | ✓                 | ✓             |              |                      |
|  <b>PV2</b> Series Anti-vandal Switch           | ✓                 | ✓             | ✓            |                      |
|  <b>PV3</b> Series Anti-vandal Switch          | ✓                 | ✓             |              |                      |
|  <b>PV4</b> Series Anti-vandal Switch          | ✓                 | ✓             | ✓            |                      |
|  <b>PV5</b> Series Anti-vandal Switch          | ✓                 | ✓             | ✓            |                      |
|  <b>PV6</b> Series Anti-vandal Switch          | ✓                 | ✓             |              |                      |
|  <b>PV7</b> Series Anti-vandal Switch          | ✓                 | ✓             |              |                      |
|  <b>PV8</b> Series Anti-vandal Switch          | ✓                 | ✓             |              |                      |
|  <b>PV9</b> Series Anti-vandal Switch          | ✓                 | ✓             |              |                      |
|  <b>PVA3</b> Series Anti-vandal Switch         | ✓                 | ✓             |              |                      |
|  <b>PVA6</b> Series Anti-vandal Switch         | ✓                 | ✓             |              |                      |
|  <b>PVL</b> Series Anti-vandal Pilot Indicator | ✓                 | ✓             |              |                      |
|  <b>PVP</b> Series Anti-vandal Switch Socket   | ✓                 | ✓             |              |                      |
|  <b>PVS7</b> Series Anti-vandal Switch         | ✓                 | ✓             |              |                      |
|  <b>PVT4</b> Series Anti-vandal Switch         | ✓                 | ✓             |              |                      |



E-SWITCH®

Beyond the Board

| ANTI-VANDAL   | Wire Leads | Solder | Screw | Quick Connect |
|---|------------|--------|-------|---------------|
|  <b>CS</b> Series Touch Sensor Switch    | ✓          |        |       |               |
|  <b>PMV6</b> Series Anti-vandal Switch   | ✓          |        |       |               |
|  <b>PZ</b> Series Anti-vandal Switch     | ✓          |        |       |               |
|  <b>SAV4</b> Series Anti-vandal Switch  | ✓          |        |       | ✓             |
|  <b>SAV7</b> Series Anti-vandal Switch | ✓          |        |       | ✓             |
|  <b>SAV8</b> Series Anti-vandal Switch | ✓          |        |       | ✓             |
|  <b>SV4</b> Series Anti-vandal Switch  | ✓          | ✓      |       |               |
|  <b>SV7</b> Series Anti-vandal Switch  | ✓          | ✓      |       |               |
|  <b>SV8</b> Series Anti-vandal Switch  | ✓          | ✓      |       |               |
|  <b>ULV4</b> Series Anti-vandal Switch | ✓          | ✓      |       |               |
|  <b>ULV7</b> Series Anti-vandal Switch | ✓          | ✓      |       |               |
|  <b>ULV8</b> Series Anti-vandal Switch | ✓          | ✓      |       |               |

### KEYLOCK

|   |   |   |   |   |
|---|---|---|---|---|
|  <b>PVK4</b> Series Anti-vandal Keylock Switch | ✓ | ✓ |   |   |
|  <b>KO</b> Series Keylock Switch               | ✓ | ✓ | ✓ | ✓ |



**E-SWITCH®**














Beyond the  
**Board**

| <b>ROCKER</b>   |                                   | <b>Wire Leads</b> | <b>PC Pin</b> | <b>Quick Connect</b> | <b>Solder</b> |
|---|-----------------------------------|-------------------|---------------|----------------------|---------------|
|    | <b>300</b> Series Rocker Switch   | ✓                 | ✓             |                      | ✓             |
|    | <b>300A</b> Series Rocker Switch  | ✓                 | ✓             |                      | ✓             |
|    | <b>400</b> Series Rocker Switch   | ✓                 | ✓             |                      | ✓             |
|   | <b>400A</b> Series Rocker Switch  | ✓                 | ✓             |                      | ✓             |
|  | <b>R1966</b> Series Rocker Switch | ✓                 | ✓             | ✓                    | ✓             |
|  | <b>R1973</b> Series Rocker Switch | ✓                 | ✓             | ✓                    |               |
|  | <b>R4</b> Series Rocker Switch    | ✓                 |               | ✓                    |               |
|  | <b>R5</b> Series Rocker Switch    | ✓                 |               | ✓                    |               |
|  | <b>R6</b> Series Rocker Switch    | ✓                 |               | ✓                    |               |
|  | <b>R7</b> Series Rocker Switch    | ✓                 |               | ✓                    | ✓             |
|  | <b>RA1</b> Series Rocker Switch   | ✓                 | ✓             | ✓                    | ✓             |
|  | <b>RA4</b> Series Rocker Switch   | ✓                 | ✓             | ✓                    |               |
|  | <b>RA8</b> Series Rocker Switch   | ✓                 | ✓             | ✓                    |               |
|  | <b>RB1</b> Series Rocker Switch   | ✓                 |               | ✓                    |               |
|  | <b>RB2</b> Series Rocker Switch   | ✓                 |               | ✓                    |               |
|  | <b>RBW2</b> Series Rocker Switch  | ✓                 |               | ✓                    |               |
|  | <b>RD1</b> Series Rocker Switch   | ✓                 |               | ✓                    |               |



**E-SWITCH®**














Beyond the  
**Board**

| <b>ROCKER</b>   |                                    | <b>Wire Leads</b> | <b>PC Pin</b> | <b>Quick Connect</b> | <b>Solder</b> |
|---|------------------------------------|-------------------|---------------|----------------------|---------------|
|    | <b>RE1</b> Series Rocker Switch    | ✓                 |               | ✓                    |               |
|    | <b>RR1</b> Series Rocker Switch    | ✓                 |               | ✓                    | ✓             |
|    | <b>RR3112</b> Series Rocker Switch | ✓                 |               | ✓                    |               |
|   | <b>R3130</b> Series Rocker Switch  | ✓                 |               |                      | ✓             |
|  | <b>RR3402</b> Series Rocker Switch | ✓                 |               |                      | ✓             |
|  | <b>RR5</b> Series Rocker Switch    | ✓                 |               | ✓                    | ✓             |
|  | <b>RR8</b> Series Rocker Switch    | ✓                 |               | ✓                    |               |
|  | <b>RRA</b> Series Rocker Switch    | ✓                 |               | ✓                    |               |
|  | <b>RRG3</b> Series Rocker Switch   | ✓                 |               | ✓                    | ✓             |
|  | <b>RRGA</b> Series Rocker Switch   | ✓                 |               | ✓                    | ✓             |
|  | <b>RSC</b> Series Rocker Switch    | ✓                 |               | ✓                    | ✓             |
|  | <b>RVW</b> Series Rocker Switch    | ✓                 |               | ✓                    | ✓             |
|  | <b>WB2</b> Series Rocker Switch    | ✓                 |               | ✓                    |               |



**E-SWITCH®**

Beyond the  
**Board**

| <b>PUSHBUTTON</b>   |   | <b>Wire Leads</b> | <b>Solder</b> | <b>Quick Connect</b> | <b>PC Pin</b> |
|---|---|-------------------|---------------|----------------------|---------------|
|    | <b>700</b> Series Snap-acting Pushbutton Switch | ✓                 | ✓             | ✓                    | ✓             |
|    | <b>D16</b> Series Pushbutton Switch             | ✓                 | ✓             |                      |               |
|    | <b>FS5700</b> Series Pushbutton Foot Switch     | ✓                 | ✓             |                      | ✓             |
|   | <b>KJD17</b> Series Pushbutton Switch           | ✓                 |               | ✓                    |               |
|  | <b>L16</b> Series Pilot Indicator               | ✓                 | ✓             |                      |               |
|  | <b>LA</b> Series Pushbutton Switch              | ✓                 | ✓             | ✓                    |               |
|  | <b>LB22</b> Series Pushbutton Switch            | ✓                 | ✓             |                      |               |
|  | <b>LP1</b> Series Pushbutton Switch             | ✓                 | ✓             |                      |               |
|  | <b>P16</b> Series Pushbutton Switch             | ✓                 |               | ✓                    |               |
|  | <b>PA4</b> Series Pushbutton Switch             | ✓                 | ✓             | ✓                    | ✓             |
|  | <b>PA5</b> Series Pushbutton Switch             | ✓                 | ✓             | ✓                    | ✓             |
|  | <b>PB1973</b> Series Pushbutton Switch          | ✓                 |               | ✓                    |               |
|  | <b>PB2</b> Series Pushbutton Switch             | ✓                 |               | ✓                    |               |

## **SNAP ACTION**








|   |                                      |   |   |   |   |
|---|--------------------------------------|---|---|---|---|
|  | <b>WS1</b> Series Snap Action Switch | ✓ | ✓ |   |   |
|  | <b>WS2</b> Series Snap Action Switch | ✓ | ✓ | ✓ | ✓ |



**E-SWITCH®**

Beyond the  
**Board**

### PUSHBUTTON (RP LINE)

|  | Wire Leads | Solder | Quick Connect | PC Pin | Screw |
|--|------------|--------|---------------|--------|-------|
|  <b>RP3508</b> Series Pushbutton Switch   | ✓          | ✓      |               |        |       |
|  <b>RP8100</b> Series Pushbutton Switch   | ✓          | ✓      |               |        |       |
|  <b>RP8200</b> Series Pushbutton Switch   | ✓          | ✓      |               |        |       |
|  <b>RP8300</b> Series Pushbutton Switch  | ✓          | ✓      |               |        |       |
|  <b>RP8400</b> Series Pushbutton Switch | ✓          | ✓      |               |        |       |
|  <b>RP8500</b> Series Pushbutton Switch | ✓          | ✓      |               |        |       |
|  <b>RP8600</b> Series Pushbutton Switch | ✓          | ✓      |               |        |       |

### SLIDE

|  |   |   |   |   |  |
|--|---|---|---|---|--|
|  <b>500</b> Series Slide Switch | ✓ | ✓ | ✓ | ✓ |  |
|  <b>EG</b> Series Slide Switch  | ✓ | ✓ |   | ✓ |  |

### TOGGLE

|   |   |   |   |  |   |
|---|---|---|---|--|---|
|  <b>ST1</b> Series Toggle Switch | ✓ | ✓ | ✓ |  | ✓ |
|  <b>ST2</b> Series Toggle Switch | ✓ | ✓ | ✓ |  | ✓ |
|  <b>ST3</b> Series Toggle Switch | ✓ | ✓ | ✓ |  | ✓ |
|  <b>ST4</b> Series Toggle Switch | ✓ | ✓ | ✓ |  | ✓ |
|  <b>ST5</b> Series Toggle Switch | ✓ | ✓ | ✓ |  | ✓ |