






E-SWITCH®

Beyond the Panel




Termination Options for
Panel Mount Switches



E-SWITCH®

Beyond the
Panel

ANTI-VANDAL		Wire Leads	Solder	Screw	Quick Connect
	PV0 Series Anti-vandal Switch	✓	✓		
	PV1 Series Anti-vandal Switch	✓	✓	✓	
	PV10 Series Anti-vandal Switch	✓	✓		
	PV2 Series Anti-vandal Switch	✓	✓	✓	
	PV3 Series Anti-vandal Switch	✓	✓		
	PV4 Series Anti-vandal Switch	✓	✓	✓	
	PV5 Series Anti-vandal Switch	✓	✓	✓	
	PV6 Series Anti-vandal Switch	✓	✓		
	PV7 Series Anti-vandal Switch	✓	✓		
	PV8 Series Anti-vandal Switch	✓	✓		
	PV9 Series Anti-vandal Switch	✓	✓		
	PVA6 Series Anti-vandal Switch	✓	✓		
	PVB3 Series Anti-vandal Switch	✓	✓		
	PVHC4 Series Anti-vandal Switch	✓	✓		
	PVL Series Anti-vandal Pilot Indicator	✓	✓		
	PVP Series Anti-vandal Switch Socket	✓	✓		
	PVS7 Series Anti-vandal Switch	✓	✓		
	PVT4 Series Anti-vandal Switch	✓	✓		



E-SWITCH®

Beyond the
Panel


ANTI-VANDAL

Wire Leads

Solder

Screw

Quick Connect

 CS Series Touch Sensor Switch				
 PMV6 Series Anti-vandal Switch				
 PZ Series Anti-vandal Switch				
 SAV4 Series Anti-vandal Switch				
 SAV7 Series Anti-vandal Switch				
 SAV8 Series Anti-vandal Switch				
 SV4 Series Anti-vandal Switch				
 SV7 Series Anti-vandal Switch				
 SV8 Series Anti-vandal Switch				
 ULV4 Series Anti-vandal Switch				
 ULV7 Series Anti-vandal Switch				
 ULV8 Series Anti-vandal Switch				

KEYLOCK

 PVK4 Series Anti-vandal Keylock Switch				
 KO Series Keylock Switch				



E-SWITCH®

Beyond the
Panel

PUSHBUTTON

	Wire Leads	Solder	Quick Connect	PC Pin
 700 Series Snap-acting Pushbutton Switch	✓	✓	✓	✓
 D16 Series Pushbutton Switch	✓	✓		
 FS5700 Series Pushbutton Foot Switch	✓	✓		✓
 KJD17 Series Pushbutton Switch	✓		✓	
 L16 Series Pilot Indicator	✓	✓		
 LA Series Pushbutton Switch	✓	✓	✓	
 LB22 Series Pushbutton Switch	✓	✓		
 LP1 Series Pushbutton Switch	✓	✓		
 P16 Series Pushbutton Switch	✓		✓	
 PA4 Series Pushbutton Switch	✓	✓	✓	✓
 PA5 Series Pushbutton Switch	✓	✓	✓	✓
 PB1973 Series Pushbutton Switch	✓		✓	
 PB2 Series Pushbutton Switch	✓		✓	
 PB66 Series Pushbutton Switch	✓		✓	

EMERGENCY STOP

 E100 Series Emergency Stop Switch	✓	✓		
 E200 Series Emergency Stop Switch	✓	✓		





E-SWITCH®

Beyond the
Panel

PUSHBUTTON

	Wire Leads	Solder	Quick Connect	PC Pin	Screw
 RP3508 Series Pushbutton Switch	✓	✓			
 RP8100 Series Pushbutton Switch	✓	✓			
 RP8200 Series Pushbutton Switch	✓	✓			
 RP8300 Series Pushbutton Switch	✓	✓			
 RP8400 Series Pushbutton Switch	✓	✓			
 RP8500 Series Pushbutton Switch	✓	✓			
 RP8600 Series Pushbutton Switch	✓	✓			

SLIDE

 500 Series Slide Switch	✓	✓	✓	✓	
 EG Series Slide Switch	✓	✓		✓	

TOGGLE

 ST1 Series Toggle Switch	✓	✓	✓		✓
 ST2 Series Toggle Switch	✓	✓	✓		✓
 ST3 Series Toggle Switch	✓	✓	✓		✓
 ST4 Series Toggle Switch	✓	✓	✓		✓
 ST5 Series Toggle Switch	✓	✓	✓		✓



E-SWITCH®

Beyond the
Panel

ROCKER		Wire Leads	PC Pin	Quick Connect	Solder
	300 Series Rocker Switch	✓	✓		✓
	300A Series Rocker Switch	✓	✓		✓
	400 Series Rocker Switch	✓	✓		✓
	400A Series Rocker Switch	✓	✓		✓
	R1966 Series Rocker Switch	✓	✓	✓	✓
	R1973 Series Rocker Switch	✓	✓	✓	
	R4 Series Rocker Switch	✓		✓	
	R5 Series Rocker Switch	✓		✓	
	R6 Series Rocker Switch	✓		✓	
	R7 Series Rocker Switch	✓		✓	✓
	RA1 Series Rocker Switch	✓	✓	✓	✓
	RA4 Series Rocker Switch	✓	✓	✓	
	RA8 Series Rocker Switch	✓	✓	✓	
	RB1 Series Rocker Switch	✓		✓	
	RB2 Series Rocker Switch	✓		✓	
	RB3 Series Rocker Switch	✓		✓	
	RB5 Series Rocker Switch	✓		✓	
	RBW2 Series Rocker Switch	✓		✓	



E-SWITCH®

Beyond the
Panel

ROCKER

	Wire Leads	PC Pin	Quick Connect	Solder
 RD1 Series Rocker Switch	✓		✓	
 RE1 Series Rocker Switch	✓		✓	
 RR1 Series Rocker Switch	✓		✓	✓
 RR3112 Series Rocker Switch	✓		✓	
 R3130 Series Rocker Switch	✓			✓
 RR3402 Series Rocker Switch	✓			✓
 RR5 Series Rocker Switch	✓		✓	✓
 RR8 Series Rocker Switch	✓		✓	
 RRA Series Rocker Switch	✓		✓	
 RRG3 Series Rocker Switch	✓		✓	✓
 RRGA Series Rocker Switch	✓		✓	✓
 RSC Series Rocker Switch	✓		✓	✓
 RVW Series Rocker Switch	✓		✓	✓
 WB2 Series Rocker Switch	✓		✓	

SNAP ACTION

 WS1 Series Snap Action Switch	✓	✓		
 WS2 Series Snap Action Switch	✓	✓	✓	✓