

Dieses Blatt gilt nur in Verbindung mit Blatt 1 des Zeichengenehmigungsausweises Nr. 40058806 .
This supplement is only valid in conjunction with page 1 of the Certificate No. 40058806

Geräteschalter
Switch for appliances

Typschlüssel / Type reference

Place-holder

Type reference E200 series							
E200	R						
1	2	3	4	5	6	7	8

1

E200 - stands for: E200 Series

2

Stands for: No Description

3

Stands for: Head Shape

Code	Description
1	Cone (Ø30*25)
2	Cone (Ø25*15)

4

Stands for: Bezel

Code	Description
1	30 mm high / 3.5 mm lock stroke
2	20 mm high / 3.5 mm lock stroke

5

Stands for: Contact Arrangement

Code	Description	Contacts	Electrical Diagram	Bottom View
A	Snap action, CLC (Only for Bezel type = 1)	1NO/1NC + 1NO/1NC		
B	Snap action, CLX (Only for Bezel type = 1)	1NO/1NC		
C	Snap action, CXC (Except for Bezel type = 1)	1NO/1NC + 1NO/1NC		
D	Snap action, CXX (Except for Bezel type = 1)	1NO/1NC		

6

Stands for: Function

Code	Function
1	Push-lock turn to reset (only for bezel type = 1, 2)

7

Stands for: Lamp

Code	Description
0	Without lamps
A	Incandescent 6V AC/DC, 200 mA
B	Incandescent 14V AC/DC, 80 mA
C	Incandescent 28V AC/DC, 40 mA
D	Incandescent 48V AC/DC, 25 mA
E	Incandescent 60V AC/DC, 20 mA
F	Neon 110V AC
G	Neon 220 V AC
H	LED 6V DC
J	LED 12V DC
K	LED 24V DC
L	Incandescent 33V AC/DC, 35mA
M	Incandescent 6V AC/DC, 40mA
N	Incandescent 14V AC/DC, 40mA
P	LED 120V AC

8

Stands for: Color

Code	Description
R	Red

